

Model name	DS830SLR
Measuring range	30 mm
Resolution	0.1 μ m
Accuracy (at 20°C)	1.5 μ m
Measuring force (at 20°C)	Downward: 0.7±0.35 N Horizontal : 0.6±0.35 N Upward : 0.5±0.35 N
Maximum response speed	80 m/min
Reference point	Position at spindle movement of 1±0.5 mm
Reference point response speed	40 m/min
Communication interface	USB2.0FS
Protection grade (Not including interpolation box and connector)	IP53 When using the DZ830BL: IP67
Vibration resistance	100 m/s ² (20 to 2000 Hz)
Impact resistance	1000 m/s ² (11 ms)
Operating temperature	0 to 50°C (no condensation)
Storage temperature	-20 to 60°C (90% RH or less)
Power supply	DC5 V±5%
Current consumption	120 mA Max.
Mass	Approx. 80 g (Not including cable and interpolation box)
Feeler	Carbide ball tip, Mounting screw M2.5
Accessories	Instruction Manual, Spanner

DS8305LR

Technical drawing of the DS8305LR cable assembly, showing dimensions in mm.

Top View Dimensions:

- Overall length: 185.5
- Distance from connector to first bend: 39.6
- Distance between bends: 45.7
- Distance from second bend to end: 169.7
- Overall width: 10.2
- Distance from end to mounting hole: 17.9
- Distance from mounting hole to end: 23
- Distance from end to mounting hole: 24.3
- Mounting hole diameter: $\phi 13.6$
- Connector diameter: $\phi 4$
- Intermediate diameter: $\phi 8$
- Intermediate diameter: $\phi 12$
- Intermediate diameter: $\phi 4.8$

Side View Dimensions:

- Overall height: 15

Detail View Dimensions:

- USB2.0TYPE-A Connector
- Cable length 0.5 m
- Interpolation box
- Distance from connector to box: 66
- Distance from connector to box: 70
- Distance from box to end: 18
- Cable length 2 m

Pin Arrangement Table:

Pin arrangement	Signal name
1	VBUS
2	D-
3	D+
4	GND

Unit: mm

©2018 Magnescape Co., Ltd.

■ Connecting the measuring unit

This measuring unit uses an interface that is compliant with the USB (Universal Serial Bus) 2.0 FS (Full speed) standard, and can be connected directly to a personal computer or hub.

■ Installing software

The software available on the Magnescale website can be used by installing in a personal computer. Refer to the software instruction manuals available on the Magnescale website for the software installation and operation methods.

■ Operating cautions


- Be sure to observe the following to prevent the product from being affected by noise from other devices.
 - Place the product 50 cm or more away from a high voltage source, large current source, large power relay, etc.
 - Provide power from a low-noise power supply.
 - When coupling relays, solenoids, motors or other devices to this product, be sure to keep the product main unit and signal output cable as far away from these devices as possible.
 - Do not arrange the signal output cable of the product alongside or parallel to device power lines. Be sure to keep the signal output cable 20 cm or more away from power lines.
 - If a strong noise source is present, take noise prevention measures such as installing a ferrite core or grounding.
- Vibration, impact, inertial force, or eccentric loads may cause the internal ball retainer to deviate from its normal position, resulting in a shorter measuring length. In such cases, perform a full stroke to correct the position of the retainer at regular operating time intervals or each certain number of reciprocations.

■ Mounting Instructions
Installation environment

- Do not use this product in places where it may receive excessive shocks. Otherwise the inside of the unit may be damaged or the unit may become unable to produce normal output signals.
- Locate the measuring unit at least 10 cm away from a strong magnetic source. (The measuring unit must not be used in magnetic fields exceeding 5 mT.)
- Do not place the measuring unit where it is exposed to splash of water or oil.


Mounting

- When attaching and removing the feeler, use the supplied spanner. Be careful not to apply torque exceeding 0.1 N·m to the spindle. This could lead to a breakdown.
To prevent the feeler from becoming loose, it is recommended to either attach the supplied spring washer (nominal size: 2.5) or use a screw lock. (tightening torque reference value: 0.05–0.06 N·m)




- Fix the cable in a suitable position to prevent possible cable breakage. Never handle the cable by forcibly pulling or bending it. (Inside bend radius 50 mm or more)
- The measuring accuracy depends on the mounting parallelism. Adjust the squareness to the measuring surface or the parallelism to the movement to within 0.02 mm/14 mm.
- After the stem is secured, do not apply force in the rotational direction. This could cause a failure.

- The measuring unit comprises ball bearings. Therefore, chucking the stem of the measuring unit too tightly when mounting may damage the spindle and prevent its smooth motion.
- Attach the stem by tightening a screw into the slot as shown in Fig. 2. Never attach by screw threading in the φ8 mm hole vertical direction, pressing the stem, and then tightening with a screw. This could result in poor sliding and low precision.
- Be absolutely sure to chuck the stem part when mounting the measuring unit.
- Using Fig. 2 as a reference, select which holder to have ready at the mounting side.



- When mounting onto a machine, use of the Flange Adaptor DZ830F (optional accessory) is recommended for preventing damage to the measuring unit due to over-tightening.
- For the mounting procedure, please refer to the Instruction Manual supplied with the DZ830F.




■ Maintenance

- Calibration is recommended every year.
- An anti-dust bellows available as an optional accessory can be mounted to the spindle part of this unit. Organic solvents, ozone, ultraviolet rays, and other adverse conditions in the ambient atmosphere can cause rapid deterioration of the anti-dust bellows. When using in these environments, replace anti-dust bellows periodically (every six months to one year).


■ When providing an IP67 protection grade

- Please use the optional DZ830BL bellows set.



■ Troubleshooting

The operating status of the measuring unit can be checked using the LED indicator.



LED lighting color	Details	Remedial action
Lights in blue.	The power is turned on. Normal operation is now performed. The reference point has been detected.	-
Blinks in blue.	The power is turned on. The reference point standby status is established or the reference point is being detected.	When the reference point is used, turn on the power with the spindle extended as far as possible (Note: in case of SV type, with the spindle contracted), and then move the spindle 1.5 mm or more. When the power is turned on with the spindle stopped near the reference point position, it may not be possible to detect the reference point or the reference point may shift.
Blinks in red.	The signal level of the measuring unit is abnormal.	After dealing with the factor suspected to be responsible for the alarm, reset the software or turn the power back on.
Lights in red.	The maximum response speed has been exceeded. The signal level of the measuring unit is abnormal. Serial communication trouble has occurred. Normal operation cannot be performed due to the effects such as external noise etc.	If the same symptoms persist even when the power has been turned back on, the measuring unit might be malfunctioned.
Off	Power OFF	If the same symptoms persist even when the power has been turned on, the measuring unit might be malfunctioned or the cable might be broken.