

Preset operation (LH72)

This describes a preset operation that sets an arbitrary value.


Up to 3 preset values can be saved.

NOTE: INC display is fixed during preset mode

Setting preset values


① Makes the preset operation possible.

Press  key. ( lamp lighting)

② Press  key for the axis you want to set.


The leftmost segment flashes.

If you have previously entered a preset value, that value will be displayed.


③ Enter the set value with the numerical keys and confirm the value with  key.

Example: -15.0000

Method 1 (simple input)




Method 2 (input all numerical values)





④ Up to 3 preset values can be set for each axis

You can enter the following preset values by pressing  key on the axis you want to set and then pressing  key.


⑤ If you have set preset values in the past, pressing  key will display the preset values in sequence.

⑥ Press  key to confirm the preset value you entered.


⑦ Press  key to end the preset operation. ( lamp off.)

The leftmost segment flashes

(Example: X-axis)






Up to 3 preset values can be set for each axis



Recall preset values

① Makes the preset operation possible.


Press  key. ( lamp lighting)



② Press  key for the axis you want to set.

The leftmost segment flashes.

If you have previously entered a preset value, that value will be displayed.

③ If you have set preset values in the past, pressing  key will display the preset values in sequence.

④ Press  key to confirm the preset value you entered.

⑤ Press  key to end the preset operation. ( lamp off.)