

LY72

LY72

Initial Setup Manual



INITIAL SETUP FLOW



Table of contents

Contents	Page
Preparations before making the initial settings (checking conditions of use)	2 to 4
How to set up Basic Settings STEP 1~3	5 to 7
How to set up Advanced Settings (continued from Basic Settings) STEP 4~5	8 to 10
Factory Default (All Clear)	11
Appendix 1: Front panel, Alarm indication	12
Appendix 2: Adapter connections (scales and gauges)	13 to 14

Preparations before making the initial setting (1/3)

By confirming the conditions of use in advance, the setting operation can be performed easily.
Let's start with the basic settings.

Pay attention to the functions that can be used depending on the selection of the axis label.

*The following functions cannot be selected when the XYZ label is selected.

- Master calibration function
- Peak value (maximum, minimum, P-P value) calculation function
- Timer output via RS-232C communication

Basic Setting Items














Items	Indication <small>(default)</small>	Description	Setting
Axis label 		Select the axis label to be used for the counter display and RS232C command. The functions that can be used differ depending on the selected axis label. ABC display: Function for gauge type measuring unit XYZ display: Functions for scale type measuring unit	Axis label: ABC or XYZ
Master calibration  NOTE: Invalid when XYZ label is selected		When the power is turned on, the system automatically waits for the reference point detection and automatically reproduces the reference position of the master block. It is necessary to adjust the reference position of the master block once before the power is turned on.	OFF: Useless ON: Effective:
Input axis 		Select how to display the number of scale axes to be connected. When you select "Additive Display", select the polarity (+/-) of each axis as well.	1: Single axis only 1 2: 2-axes independent display 1 2 3: 3-axes independent display
Destination country 		Please select the region to be used.	STD: General Area  US: U.S.A.  JPN: Japan 
Measuring unit resolution 		Set the resolution output from the measurement unit to be used for each axis. The resolutions that can be selected are length and angle. Expanded selections increase the number of options. *Angular resolution (1sec to 1 degree) when using a rotary scale	Length: 0.05 to 100μm *See Tables 1,2 and 3 or Angle: 1 second to 1 degree

Table1: Length scale output resolution

Measuring Unit	Output resolution	connection cable	Adapter *
SR-1711 SR-1711R	0.5μm	HK-**C HK-**CR	SZ05-T01
SR801/ MSS-101 SR801R	0.5μm	HK-1**C HK-2**C	SZ05-T01
SR801/ MSS-101 SR801R	0.5μm	CE07-**C	SZ51-MS01 + SZ70-1
SR10 / SR30 / SR50 SR50-R	0.5μm	HK-4**C HK6-**CR	SZ05-T01
SR118	0.5μm	CE05-**C CH02-**	DZ51 + SZ70-1
SR108 SR107	0.5μm		SZ51-MS01 + SZ70-1
SR128	0.5μm	CH01-**C	SZ70-1
SR128 / SR127	0.5μm	CH01-LW**C	SZ51-MS01 + SZ70-1
SR138R(GB-ER)	0.5μm	CH04-03C	

Table 2: Digiruler output resolution

Measuring Unit	Output resolution	Adapter/ conversion cable	Adapter *
SL110 SL130	10μm	PL20B	SZ70-1
SL110 SL130	10μm	PL20C	
SJ300	1μm	CH33-**CPD/CED	
SJ700	5μm		SZ70-1
SJ700A	5μm		

Table3: Digital gage output resolution































Measuring Unit	Output resolution	Adapter/ conversion cable	Adapter *
DG	0.5μm		SZ05-T01
DG-B	0.5μm	DZ-51	SZ70-1
DL310B/330B	10μm	DZ-51	SZ70-1
DK series	0.1μm or 0.5μm	CE29-**	

* For adapter information, refer to Appendix 2 Adapter Connection in this Manual

Preparations before making the initial setting (2/3)

Check the usage conditions for Advanced Settings.


















Advanced Setting Items

Items	Indication <small>(default)</small>	Description	Setting
Display at Power-ON 		Select the display when the power is turned on If you select "LY", "LY" will be displayed and recognized when the power is cut off.	COU n T: count display LY: "LY" display <small>(default)</small>
Display resolution and polarity 		Set the resolution of each display axis You cannot set a value smaller than the input resolution. Also select the polarity (+/-). * The initial value is the measurement unit resolution set in the basic settings.	Length: 0.05 to 100μm or Angle: 1 second to 1 degree
Display axis and display data 	Upper axis  Middle axis  Lower axis 	Set the display contents when the power of each display axis is turned on Set axis input axis number and display data * At the time of shipment, the current values are displayed for all three axes. * When the XYZ label is selected, display selection other than the current value is not possible.	Input axis number: 1, 2, 3 Display data: Present value Maximum value Minimum value P-P value Do not show
Scaling 		Displayed by multiplying the measured value by a magnification	0.1 times to about 10 times
Linear compensation 		Set a linear compensation value for the length per 1 m	±600μm/m *Expanded selections ±1000μm/m
Hole function 		Function selection during hold operation (operation key, external input)	LATCH: Latch function PAUSE: Pause function
General-purpose input  NOTE: Invalid when XYZ label is selected	Upper axis  Middle axis  Lower axis 	Function selection of general-purpose input (1 circuit each) for 3 display axes - Hold: Holds the display (holds on the first input and cancels on the second input) Furthermore, holds the update of the peak calculation when the ABC label and pause function are selected. - Restart: Recalculate the maximum / minimum value - Display switching: Switching between the current value and the selected display (maximum value, minimum value, peak value) - Origin load: Reproduction of reference position - Recall: Recall preset values	Hold Restart.(When ABC label is selected) Display switching(When ABC label is selected) Reference point Load Recall (preset value)
General-purpose output 	Upper axis  Middle axis  Lower axis 	Function selection of general-purpose output (1 circuit each) for 3 display axes - Alarm: Output when Error is displayed - Display mode: Current value or peak value - Origin passing signal: Output when the origin is passed during origin operation - Origin alarm: Output when the origin signal is not connected and the origin speed is exceeded.	Alarm <small>(default)</small> Display mode (When ABC label is selected) Reference point passage signal Reference point alarm
Key lock 		Function to prevent erroneous operation of Key operation After setting, only a specific key can be used. A password (1793) is required to unlock it.	OFF: No key lock ON: Key lock
Current value store 		Select whether to display the previous value when the power is turned on * If you use the master alignment function in the basic settings, it will not work even if it is turned on.	OFF: Don't save the current value ON: Save the current value
Flicker control 		Prevents flickering of the smallest digit to be displayed Set the stage to suppress flicker.	OFF: Function stop 1: Weak 2: Strong
Sleep 		The display turns off when there is no movement of the length measurement unit or key operation for a certain period of time while the power is on. It will return when the length measurement unit is moved or the Key operation is performed again.	OFF: Do not put to sleep 1: 1 minute later 5: 5 minutes later 10:10 minutes later 30:30 minutes later 60:60 minutes later

Preparations before making the initial setting (3/3)

Check the advanced settings for RS232C communication.

Advanced Setting Items

Items	Indication <small>default</small>	Description	Setting
RS232C Output data mode 		Set the output data mode when receiving the data request command ("R"). Outputs data for 3 axes in computer mode, and outputs data for 1 axis in print mode.	- COMP: Computer mode <small>default</small> ABC axis output or XYZ axis output - Print : Print mode Output only A axis (when ABC label is selected) or Output only X axis (when XYZ label is selected)
RS232C Output data format  <small>Invalid when print mode is selected</small>	When ABC is selected  When XYZ is selected 	Select the output data format. • All lines output in one line • Line feed and output • Add a header The selectable items differ depending on the axis label (ABC or XYZ)	When ABC label is selected: <small>default</small> AbC : Outputs one line for all axes without header A.b.C. : New line output for each axis without header h1AbC : Header 1 outputs one line for all axes h1A.b.C: Header 1 outputs line feed for each axis When XYZ label is selected: XYZ : Output with 1 line for all axes without header X.Y.Z. : New line output for each axis without header h1XYZ : Header 1 outputs 1 line for all axes h1X.Y.Z.: New line output for each axis with header 1 h2XYZ : Header 2 outputs one line for all axes <small>default</small> h2X.Y.Z.: Line feed output for each axis with header 2
RS232C Output data selection  <small>Invalid when XYZ label is selected</small>		Set the output data when receiving the data request command ("R"). • Present value • Maximum value • minimum value • P-P value	When ABC label is selected: Cr : Current value MAX: Maximum value MIN : Minimum value P-P : P-P value *Cannot be set when XYZ axes are selected.
RS232C timer  <small>Invalid when XYZ label is selected</small>		The data specified by the "R" command can be output at fixed intervals.	Setting range: None 0.2, 0.5, 1, 5, 10, 30, 60, 300 (sec.) *Cannot be set when XYZ axes are selected.
RS232C transfer rate 		Set the transfer rate of RS232C	Setting range: 1200, 2400, 4800, 9600, 19200, 36400 (bps)
RS232C parity 		Set RS232C parity	Setting: none Odd number Even number
RS232C Stop bit 		Set the stop bit of RS232C	Setting: 1bit 2bit
RS232C data length 		Set the data length of RS232C	Setting: 8bit 7bit

How to set up Basic Settings (1/3)

Step 1

Configure the basic settings.

Choose one of the following methods of operation.



NOTE: If you change the basic settings, Detailed Settings will be reset to the factory defaults.

When the power is turned on for the first time after shipment from the factory

Connect the AC adapter and turn the primary power "on".


When you want to change the basic settings

AC adapter is energized.


Turn on  key, the LED light changes from "blinking" to "off" and then press and hold  key for 3 seconds.

The following display appears


Connecting the AC Adapter



AC primary power source




After about 2 seconds



"Axis label selection" setting display

Continued on next page

Pressing  key changes the basic setting mode in the order in which it is set.



Axis LABEL

Cannot be set when XYZ label is selected



MASTER

Master calibration


MASTER (Master calibration function):
Select whether to start with the master block or other dimensions every time the power is turned on.



SIG IN

Input axis

SIG IN (input axis):
Set the 1-axis, 2-axis, and 3-axis (Setting the number of display axes)



COUNTRY

Destination

COUNTRY (destination country):
Please select your region



SIG RES

Measuring unit resolution

Signal resolution (measuring unit resolution):
Sets the output resolution of the scale to be connected. Supports the input of length and angle display units.

COUNTRY (Destination)

Symbol	Destination	Unit
STD 	General area	
US 	U.S.A.	
JPN 	Japan	

NOTE: Selection of axis label

ABC display: Function for digital gauge type measuring unit




XYZ display: Function for length scale type measuring unit

The functions that can be used vary depending on the axis label selection.


How to set up Basic Settings (2/3)

Step 2

Enter the settings confirmed in "Preparations before making initial settings (1/3)".
Repeat steps (1), (2), and (3) to make the basic settings.

- (1) Use  key to change the basic setting item.
- (2) The setting selection can be switched with  key on the right side of the counter display.
- (3) To define the new value, press  key.

Basic Settings









How to set up Basic Settings (3/3)

Step 3

Once you have completed the basic settings, exit this mode and move to the advanced setting mode.


How to Exit Basic Setting Mode

- ① Press  key or  key.
- ② The display changes to  (CANCEL).
- ③ Pressing  (key displays  (FINISH).
- ④ Press  key.

If this is the first time you have made basic settings after shipping, the display will be




After the second time, the screen is displayed when the power is turned on.

- ⑤ Press  key. The display returns to normal.

This completes the basic settings.

Key to be used at the end of the basic setting mode (LY72)



How to set up Advanced Settings (1/3) (continued from Basic Settings)

Step 4 Make the advanced settings.

*If you have already completed the basic settings and want to reconfigure only the advanced settings, you can do the same.


Advanced Settings

Basic Settings

Press the setup key in the normal count display state.


Operation:

- The current setting is displayed after about one second. If there is no change in the setting, the next item is displayed with key.
- The ABS lamp blinks while the parameter is selected with the axis selection key..



Power On Display Display at power-on

The display at power-on can be set.




* If you select the count display, you cannot make basic settings.

Display resolution

Press keys for each axis to set the display resolution for each axis.

(NOTE 4)



After setting, use key to set the resolution for each axis.

Change polarity with key


NOTE 1: Selection of a value smaller than the input resolution of the basic setting is not displayed.

NOTE 2: To display the diameter, turn on the Φ lamp.

NOTE 3: The angle display can be selected when the angular resolution is selected in the basic settings.

Length display (NOTE 1)

Diameter display (NOTE 2)



Angle display (NOTE 3)


INPUT CHANGE Display axis and display data

Selection of display format when power is turned on for each display axis (A / B / C)

1. Press key to set to select the axis, then select the input axis, and when confirmed, press key to set.
2. Continue to press key to select the display data, and when confirmed, set with key

* You need to restart the main unit for the settings to take effect.

* When the XYZ axes are selected, only the current location can be set.



SCALING

Enter scaling factor

default 1x

Enter numerical values on a numeric keypad.

0.000000 ≤ magnification ≤ 9999999

Liner Error (Linear compensation)

default

Enter a correction value of $\pm 0.600\text{mm}$ per 1m of distance Input up to $\pm 1.0000\text{mm}$ with expansion selection.

Enter numerical values on a numeric keypad.


Normal

-0.6000 ~ 0.6000

Extended selection


-1.0000 ~ 1.0000

How to set up Advanced Settings (2/3)



Hold function selection

LATCH: The display data is fixed without interrupting the internal calculation.
PAUSE: Holds peak calculation (temporarily suspends calculation of maximum and minimum values)




Function selection of general-purpose input (1 circuit each) for 3 display axes

* Some items may not appear when the axis label XYZ is selected.

key for the axis to change

key to decide the selection




Function selection of general-purpose output (1 circuit each) for 3 display axes


* Some items may not appear when the axis label XYZ is selected.

key to change


key to decide the selection




Key lock function can be set (to prevent accidental operation)




It is possible to save the display at power-off and display the value at power-on.




Flickering of the smallest digits can be suppressed in two stages.




If no operation or scale movement is performed for a certain period of time, the display will turn off.




How to set up Advanced Settings (3/3) RS232C function setting



RS232C output data mode selection




Select the output data format when selecting the computer mode




Select default settings for output data


(Output data can be changed by RS232C command)



Set automatic data output at fixed time intervals (unit: ms)




Select the transfer rate of RS232C (unit: bps)




Select RS232C parity check



Select stop bit of RS232C



Select RS232C data length



Step 5

When the advanced settings are complete, switch to the normal display.

Press key.


This completes the initial settings.

Factory setting (All clear)

To set the factory settings (all clear), perform the following operations.
Make preparation such as taking notes in advance for necessary items.
Also, do not perform any operation other than the explanation.

CAUTION: IF YOU DO THIS, ALL SETTINGS WILL BE THE FACTORY DEFAULT SETTINGS.


Mainly used keys






Reference key

Setup key




Connecting the AC Adapter





1. Hold down  key and  key at the same time to start the power supply.

⇒ The model name of the counter is displayed 

Connect the AC adapter to the DC-IN input on the back of the counter and turn on the primary power supply.


2. When you press  key,  (slf_tst) is displayed,
followed by  (Tst Sel)

3. Pressing  key changes the display as shown below.




4. Turn off the primary power supply to the AC adapter.

How to check the software version:

Power ON → Display LY →  Key → Version
Press any key to return to the LY display.

Appendix 1

Front panel



No.	Name	No.	Name	No.	Name
①	Axis label	⑦	P key	⑬	PRINT key
②	ABS lamp	⑧	Datum point value/Master combination value setting key	⑭	Standby key
③	Φ lamp	⑨	REF key	⑮	Numeric key
④	Counter display	⑩	ABS/INC key	⑯	Function key
⑤	RESET key	⑪	SETUP key	⑰	Peak value lamp
⑥	Axis select key	⑫	HOLD key		

Alarm indication

Display	Status	Display	Status
	Measurement unit not connected		Storage data error
	Speed over (NOTE)		Reference point detection error
	Overflow		
	Power failure		


NOTE: When using an adapter connection (SZ**), no speed override indication is shown, but rather an error message.




Appendix 2-1

Adapter connection (Length scale)

Scale/ Head	Resolution	Adapter	Counter
SR128(GB-A)	0.5μm	SZ70-1	LG20
PL20B	10μm		LH70/71/71A/72
SJ700	5μm		LY71/72




Scale/ Head	Resolution	Adapter 1	Adapter 2	Counter
SR108(GB)	0.5μm	SZ51-MS01	SZ70-1	LG20
PL20A	10μm	SZ51-DR01		LH70/71/71A/72 LY71/72



Scale	Resolution	Adapter	Counter
SR-1711(GP), SR10A/741(GS), SR50A(GF,GF-R), SR30A(GM), SR801/801R(GL)	0.5μm	SZ05-T01	LG20 LH70/71/71A/72 LY71/72

* HA13A, 15A, 23A and 25A are used as head amps




Appendix 2-2


Adapter connection (Digital gauge)




Gauge	Resolution	Connection cable	Counter
DK- ^{**}	0.1μm or 0.5μm	CE29- ^{**} ^{**} : 003/01/03/05/10 (0.3 to 10m)	LG20 LH70/71/71A/72 LY71/72



Gauge	Resolution	Adapter 1	Adapter 2	Counter
DG-B	0.5μm	DZ51	SZ70-1	LG20 LH70/71/71A/72 LY71/72
DL310B/330B	10μm			



Gauge	Resolution	Adapter	Counter
DG	0.5μm	SZ05-T01	LG20 LH70/71/71A/72 LY71/72



Gauge	Resolution	Adapter	Counter
DE12BR/30BR	0.1μm	SZ70-1	LG20 LH70/71/71A/72 LY71/72

