

SmartSCALE

SQ47

Installation manual



This manual is a reference material for easily and correctly mounting the SQ47 using a special jig.

Please use this manual when installing the SQ47 for the first time.

Please use this manual together with the instruction manual attached to the main unit.

Table of contents

1. Precautions for installation location	3
2. How to install the scale	
2-1. Preparing the scale mounting bracket	5
2-2. Confirmation of scale and sensor head mounting surface	6
2-3. Track position of sensor head and scale	7
2-4. Installation procedure ① to ⑧	8
3. How to check the scale signal	
3-1. AC20-B100 Monitoring System	15
3-2. AC20-B100 Screen caption (Ver. 1.03.0)	16
3-3. When AC20 does not automatically recognize the scale	17
4. Installation using the positioning jig	
4-1. Position of head bracket with respect to the positioning jig	18
4-2. . Installation procedure ① to ⑨	19
5. Installation tool (option)	21
6. Dimensional diagrams of dedicated jig (Reference material)	
Track position confirmation jig	22
Positioning jig(SQ47)	23
SZ30 (CH22/23 dedicated socket) processing dimensions	24

MEMO:

SQ47 has a structure in which the scale and the sensor head are separated. The machine side needs to satisfy the scale mounting tolerance within the range of effective scale length for the mounting posture of the scale and sensor head.

It is recommended to use the installation tool and positioning jig when installing.

By using the installation tool and positioning tool, you can easily and correctly install and check the installation status.

1. Precautions for installation location

Consider the following points when mounting the scale.

#1 Clearance of sensor head to scale surface

The clearance between the scale surface and the sensor head is kept constant

The clearance between the scale surface and the sensor head is not stable

Sensor head

Scale

movement

Clearance fluctuation

movement

2 Roughness of scale mounting surface

Scale mounting standard is flat, no unevenness

The mounting surface is uneven


Mounting reference surface is curved

Scale

3

Securing the scale contact surface


A guideline for the characteristic frequency of the mounting bracket is 600 Hz or more
* Vibration analysis is also possible with CAD data of bracket



4

Rigidity of sensor head mounting bracket


A guideline for the characteristic frequency of the mounting bracket is 600 Hz or more
* Vibration analysis is also possible with CAD data of bracket




2. How to install the scale

2-1. Preparing the scale mounting bracket

Prepare the brackets required for installing the scale.




Installation example using parallel pins



2-2. Confirmation of scale and sensor head mounting surface

For the scale mounting surface and sensor head mounting position (head bracket), consider the following allowable mounting values.




MG : Machine guide

Unit: mm


2-3. Track position of sensor head and scale

Pay attention to the track position of the sensor head and scale (center of scale and center of head).
If the track position shifts, it will not operate normally.

The center line (CL) tolerance of the scale and head is **$CL \pm 0.5\text{mm}$**



When mounting the actual scale, you can check the track position of the sensor head with respect to the scale if there is a space where a jig can be used either on the front side or the back side of the scale.




Unit: mm

2-4. Installation procedure ① to ⑧


Step①: Preparation of scale bracket

Make sure parallelism of the stop surfaces or parallel pins is within 0.1mm to MG (Machine guide) and parallelism of the scale mounting surface is within 0.05mm to MG.

<When using the stop surfaces>



<When using parallel pins>




If the effective length is 1000 mm or less, Two ϕ 6 mm pins (38 mm from both ends of the scale) are recommended




Step②: Preparation of sensor head bracket

Make sure parallelism of the sensor head bracket is within 0.1mm to the scale mounting surface or MG and squareness of the sensor head is within 0.05mm to the scale mounting surface. Then make sure sensor head mounting surface position is 16.5 ± 0.5 mm from the stop surface or parallel pins. (Thickness of sensor head:20mm)

<When using the stop surfaces>




<When using parallel pins>




Step③: Scale installation

Contact the scale to the stop surfaces or parallel pins and fix by the screws supplied with the scale unit.


Note: In case of use of other non-supplied screws, the screw head may project from mounting surface. Do not use a screw with large "R" or no screw threads at base part as shown below.



<When using the stop surfaces>



<When using parallel pins>



Step④: Check the sensor head direction and peel the label off


Make sure that the serial numbers of the sensor head and scale are the same.

Check the direction of the head cable with the label.

Please peel off the label after confirmation, otherwise the clearance confirmation will not be correct.

Confirm sensor head direction


Same serial number




Note:

If the combination has different serial numbers, it will not work properly.


Cable left direction type




Serial number and model name




* Reversed from the front



Cable right direction type



Serial number and model name




Step⑥: Mount the sensor head (Clearance and pitch adjustment)


Adjust the clearance between the scale surface and the sensor head detecting part to $0.185^{+0.065}_{-0.085}$ mm with the clearance gauge t0.185 (supplied with the scale unit).

Clearance adjustment and pitch adjustment can be performed at same time by using a clearance/pitch adjustment spacer SZ26 (sold separately).



<When using the stop surfaces>



<When using parallel pins>




Insert the SZ26 between the sensor head and the scale. Then fix the sensor head under condition of light contact at both ends.





Remove the SZ26 and make sure t=0.1mm gauge should enter the gap and t=0.25mm gauge should not enter the gap.

<When using the stop surfaces>




<When using parallel pins>



Step ⑦-1: Check the track position (from the front)

1. To check the track position from the front of the scale, prepare an appropriately sized block and spacer.




Spacer of appropriate size
Include several sheets with a thickness of 0.1 mm





Spacer
Size 18 x 50 mm or more
Thickness t=0.4x1 piece, 0.1x2 piece (reference)

2. Push the block against the scale base surface and check the gap between the sensor head and the block with a spacer.



The gap between the left and right check surfaces and the block is **0.5 ± 0.5 mm** with the spacer.



Step ⑦-2: Check the track position (from the back)

1. To check the track position from the back of the scale, prepare the track position check jig and spacers.



Track position check jig
(Refer to p.24 for Dimensional diagrams)



Spacer of appropriate size
Include several sheets with
a thickness of 0.1 mm




Spacer
Size 18 x 50 mm or more
Thickness t=0.4x1 piece, 0.1x2 piece
(reference)

2. Push the jig against the scale base surface
and check the gap between the sensor head and the jig with a spacer.

The space between the left and right check surfaces and the
block on the spacer is $(16.5-16.1) \pm 0.5$ mm. (Do not enter 0.5 mm)

Depends on the thickness of
the track position jig




Surface to check


Screw to
the scale base
(M4x16)



Be careful of the screw length!
If it is long, it will hit the bottom



Push the block to the scale base



Scale part

Jig

Scale base

Step⑧: Connect the cable


Remove the waterproof cap and connect the connection cable. (Waterproof cap 5mm across flats)

Before tightening the connector, make sure that the two O-rings have not come off.


(If the O-ring is dropped, waterproofness will be significantly reduced.)

Place the cable-side connector against the sensor head connector in a straight line, align the mating key, and insert it.


- Tighten the connector with the specified tightening torque.
- If the connector is not tightened sufficiently, there is a possibility that coolant may enter through the gap.
- Do not over-tighten the connector with excessive torque, otherwise the connector may be damaged.



Make sure it has two O-rings!




Connector diameter



When there is no space to use a torque wrench

Please use the installation tool SZ30 (CH22/23 dedicated socket) that is used by combining the torque driver and socket adapter.




3. How to check the scale signal


3-1. AC20-B100 Monitoring System

To check scale signal, the AC20-B100 (sold separately) is used.

Need to install the software prior to use. Please refer the AC20 instruction manual for details.

Needs a special adaptor cable to connect with the scale as well.

<p>AC20-B100 signal checking tool</p> 	<p>Adaptor cable</p> <ul style="list-style-type: none"> CE35-02 (for Mitsubishi control) CE36-02 (for Fanuc control) CE36-02T01(for Yasukawa control) CE37-02 (for Siemens DQ control)
--	---



System requirement

Item	Environment
CPU	Intel Core i3 or higher
RAM	1GB or higher
OS	Windows 7 (32bit/64bit) Windows 10 (32bit/64bit)
Display	1080 x 800 pixels or higher
USB	2.0

3-2. AC20-B100 Screen caption (Ver. 1.03.0)

Scale signal (Lissajous waveform), sensor head clearance and alarm status can be checked by a AC20-B100.

Head clearance condition for overall length can be monitored by the bar graph. **Make sure red indication does not appear.**

■ Procedure at the starting: All connections with AC20 ⇒ [Power supply switch] ON ⇒ [Measuring switch] ON

■ Procedure at the end: [Measuring switch] OFF ⇒ [Power supply switch] OFF ⇒ Remove the scale connection cable

*Power is supplied to the scale from AC20. Use two USB cables to prevent power shortage.

*AC20 automatically recognizes the scale when it starts, but if it does not, refer to the next page for operation.

The screenshot shows the Magnescape SmartSCALE Absolute software interface. Key components are labeled as follows:

- Model selection tab:** Located at the top left, showing the selected model 'SQ57/SQ47'.
- Power supply switch to scale:** A control panel with 'White letters: OFF' and 'Blue letters: ON'. A note states '*Number is AC20 serial number'.
- Scale information:** A box containing 'Model', 'Serial number', and 'Communication protocol'.
- Software version:** A box showing the version '01.03.00'.
- Current position:** A box pointing to the large numerical display '-61.62648 mm'.
- Signal strength indicator:** A box pointing to the 'Sig Level [%]' bar graph.
- Screen capture button:** A box pointing to the 'Scale Info' and 'Setting' buttons in the top right.
- Alarm information:** A box pointing to the 'Status' section, which lists 'Speed Error', 'Signal Level Error', 'ABS Error', and 'Other Error'.
- Measurement switch:** A box pointing to the 'Measure' button.
- Clearance status for the position on the scale:** A box pointing to the bottom bar graph, which shows a green bar indicating the current position is within the appropriate range.
- Scale signal (Lissajous waveform):** A box pointing to the central circular plot, which displays a Lissajous waveform between two circles.

Additional information from the interface:

- Information:** Product Name: SQ57-037SAAX, Serial Number: 000000, Protocol: FANUC.
- Measured Data for User:** Record: 18678, Save, Data Clear.
- Adjust Level:** Info: Sin: -0.90625, Cos: -0.46484, Adjust: 79.7. Adjust Level: Good.
- Bar Graph:** Shows 'Sig Level [%]' and 'Adjust Level' with a scale from 0.0 to 120.0. The 'Adjust Level' is currently at 79.7.
- Bottom Bar Graph:** Shows clearance status with a scale from -185 to 185. The current position is at -61.62648 mm.

3-3. When AC20 does not automatically recognize the scale

AC20 may not recognize the connection scale automatically.



1. If AC20 version is old ⇒ Install new version
2. If the scale model is not a standard product ⇒ Enter the scale model name and let AC20 recognize it

If automatic recognition is not performed, the screen for entering the following scale information will appear immediately after the [Power supply switch] is turned on.

On this screen, AC20 recognizes the scale by inputting all the scale model names with a hyphen.

【Procedure】


- ① Screen that appears when AC20 does not automatically recognize the connection scale



Confirmation of scale model name

Enter the model name information of the scale


- ② Enter the model name written on the scale model name label with a hyphen.
Example) SQ47-037SAFX



- ③ After entering all scale type names, press the "tab key" on the keyboard. The basic scale information is automatically displayed from the entered scale model name.

Press the "tab key"

- ④ When the scale information is updated, click the "Setting key" on the screen



Recognize and display scale information

- ⑤ Change to the initial screen

Click [Measuring switch] ON on the screen to start measurement!

that's all


4. Installation using the positioning jig

The positioning jig explained here is a jig that correctly reproduces the position of the mounting bracket of the linear scale (SQ47). Explanations are given using the stop surfaces type bracket and head bracket. If this jig is not suitable due to the mechanism and configuration of your machine, please use it as a reference material to create a jig suitable for your machine.

*For the dimensional diagrams of positioning jig, refer to page 23 in this manual.

4-1. Position of head bracket with respect to the positioning jig

Check the position of the head bracket and the screw tightening direction by referring to the mounting example below.



<p>Mounting bracket (head fixed from the back)</p> <p>This diagram shows the head bracket fixed from the back. The scale bracket is on the left, and the head bracket is on the right. The positioning jig is positioned below the scale bracket. Labels include 'Head bracket', 'Scale bracket', and 'Positioning jig'.</p>	<p>Mounting bracket (head fixed from the front)</p> <p>This diagram shows the head bracket fixed from the front. The scale bracket is on the left, and the head bracket is on the right. The positioning jig is positioned below the head bracket. Labels include 'Positioning jig', 'Scale bracket', and 'Head bracket'.</p>
<p>Screw tightening direction</p> <p>This diagram shows two views of the screw tightening directions for the back-fixed head. In the first view, an M8 screw is tightened from the left and an M6 screw from the top. In the second view, an M6 screw is tightened from the left and an M8 screw from the right. Labels include 'Positioning jig', 'M8', and 'M6'.</p>	<p>Screw tightening direction</p> <p>This diagram shows two views of the screw tightening directions for the front-fixed head. In the first view, an M6 screw is tightened from the left and an M6 screw from the top. In the second view, an M6 screw is tightened from the left and an M8 screw from the right. Labels include 'Positioning jig', 'M6', and 'M8'.</p>


4-2. Installation procedure ① to ⑨

* This is an example of using the stop surface type bracket for the scale bracket.

Step ①: Fixing the scale bracket


After temporarily fixing the scale bracket to the machine side, check the parallelism with the machine guide and then fully tighten it.

<When using the stop surfaces>




Step ②: Fix the positioning jig

Attach the positioning jig to the appropriate position on the scale bracket.




Step ③: Installation of head bracket

Temporarily fix the head bracket.





Step ④: Fix the head bracket

Fix the head bracket to the machine side.




Step ⑤: Removal of positioning jig

Remove the screw fixing the head bracket, move the device, and Slide the head bracket and check the position of the head bracket. After checking, remove the positioning jig.



Step ⑥: Scale installation

Place the reference mounting surface on the scale side in close contact with the stop surface of the scale bracket, and fix with the mounting screws provided.




Note: In case of use of other non-supplied screws, the screw head may project from mounting surface. Do not use a screw with large "R" or no screw threads at base part as shown below.

Mount with accessory screws

Step ⑦: Check the sensor head direction and peel the label off

Step ⑧: Mount the sensor head (Clearance and pitch adjustment)

Step ⑨: Cable connection



See 「2. How to install the scale」 of this manual

- Step ④: Check the sensor head direction and peel the label off (P9)
- Step ⑥: Mount the sensor head (Clearance and pitch adjustment) (P11)
- Step ⑧: Cable connection (P14)


5. Installation tool (option)

SZ26

Clearance and pitching adjustment spacers:

With respect to the scale, the sensor head clearance and positioning in the pitching direction can be easily done.

t=2.0



SZ26

SZ30 (AM-000-820-1)

CH22/23 dedicated socket:

Effective in places where a torque wrench cannot be used.

A torque control product can be made by combining with a torque driver.



AC20-B100

Signal checking tool:

You can check the scale signal and clearance after installing the scale. You can also check the signal when an error occurs.

The AC20 software must be installed on your PC in advance.

A dedicated cable for connecting to the scale must be prepared separately.



AC20-B100

Adaptor cable

CE35-02 (for Mitsubishi control)


CE36-02 (for Fanuc control)

CE36-02T01 (for Yasukawa control)

CE37-02 (for Siemens DQ control)


6. Dimensional diagrams of dedicated jig (Reference material)

Track position confirmation jig (from the back)




*This jig is a reference example.
Please refer to this outline drawing and scale outline drawing when creating a jig suitable for your equipment.

Material: Aluminum or Stainless




A block



Unit: mm

B block




Note 1: No burrs on each surface, chamfering of unspecified corners is C0.5 or less
Note 2: For assembly, 3 hexagon socket head bolts M4x16

SZ30 (CH22/23 dedicated socket) processing dimensions

*This jig is a product of TONE Corporation.
Please refer to this processing drawing when you process.

External dimensions (before processing)




Manufacturer: TONE Co., Ltd.
Name: Super long socket
Model name: 3S-12L120

Product No.	Width across flats (mm) S	Dimension (mm) D1	Dimension (mm) D2	Dimension (mm) L1	Dimension (mm) L	Dimension (mm) d
3S-12L120	12	16.8	17.3	8.0	120.0	11.0

Processing dimension

√ Ra 6.3

Processing: Chrome plating



Note:

- 1) This part shall not use materials containing substances specified in RMS-0002: Product Environmental Technology Standard.
- 2) In the rear part after addition, the unindicated corner part shall be C0.05 or less.
- 3) Re-plate after additional machining.